
XC4460 Connections:



Servo Input:

| Board Connection | Arduino Connection | Function |
|------------------|--------------------|--------------------|
| GND | GND | Ground connection |
| S 1 | Digital servo pin | Signal for Servo 1 |
| S2 | Digital servo pin | Signal for Servo 2 |
| S3 | Digital servo pin | Signal for Servo 3 |
| S4 | Digital servo pin | Signal for Servo 4 |

Motor input 1:

| Board Connection | Arduino Connection | Function |
|------------------|---------------------|-------------------------------|
| +5 | 5V | Power (can be fed to Arduino) |
| GND | GND | Ground connection |
| IN1 | Digital pin | Control for OUT1 |
| IN2 | Digital pin | Control for OUT2 |
| IN3 | Digital pin | Control for OUT3 |
| IN4 | Digital pin | Control for OUT4 |
| EN1 | PWM pin (or jumper) | Enable for OUT1 and OUT2 |
| EN2 | PWM pin (or jumper) | Enable for OUT3 and OUT4 |

Motor input 2:

| Board Connection | Arduino Connection | Function |
|------------------|---------------------|-------------------------------|
| +5 | 5V | Power (can be fed to Arduino) |
| GND | GND | Ground connection |
| IN5 | Digital pin | Control for OUT5 |
| IN6 | Digital pin | Control for OUT6 |
| IN7 | Digital pin | Control for OUT7 |
| IN8 | Digital pin | Control for OUT8 |
| EN1 | PWM pin (or jumper) | Enable for OUT5 and OUT6 |
| EN2 | PWM pin (or jumper) | Enable for OUT7 and OUT8 |

Output LEDs:

| LED | Output |
|-----|--------|
| D2 | OUT2 |
| D3 | OUT1 |
| D4 | OUT4 |
| D5 | OUT3 |
| D6 | OUT6 |
| D7 | OUT5 |
| D8 | OUT8 |
| D9 | OUT7 |

Motor Output 1:

| Board Connection | Motor Connection | Function |
|------------------|------------------|------------------|
| OUT1 | Motor 1+ | Motor 1 forward |
| OUT2 | Motor 1- | Motor 1 backward |
| OUT3 | Motor 2+ | Motor 2 forward |
| OUT4 | Motor 2- | Motor 2 backward |

Motor Output 2 and Power Input:

| Board Connection | Motor Connection | Function |
|------------------|------------------|----------------------------|
| OUT1 | Motor 1+ | Motor 1 forward |
| OUT2 | Motor 1- | Motor 1 backward |
| OUT3 | Motor 2+ | Motor 2 forward |
| OUT4 | Motor 2- | Motor 2 backward |
| VDD | N/A | Positive supply into board |
| GND | N/A | Negative supply into board |

Stepper 1:

| Board (from left) | Stepper Connection | Function |
|-------------------|--------------------|----------|
| 1 | Common | Common |
| 2 | Phase 1 | OUT3 |
| 3 | Phase 2 | OUT4 |
| 4 | Phase 3 | OUT2 |
| 5 | Phase 4 | OUT1 |

Stepper 2:

| Board (from left) | Stepper Connection | Function |
|-------------------|--------------------|----------|
| 1 | Common | Common |
| 2 | Phase 1 | OUT7 |
| 3 | Phase 2 | OUT8 |
| 4 | Phase 3 | OUT6 |
| 5 | Phase 4 | OUT5 |

Servo Output:

The + on these headers is fed straight from the power input, and not through the regulator. Eg If you feed 9V into the board, servos connected to this header will receive 9V.

| JST Header | Servo |
|------------|---------|
| S1 + - | Servo 1 |
| S2 + - | Servo 2 |
| S3 + - | Servo 3 |
| S4 + - | Servo 4 |