

# Centralized Monitoring Software

## Wifi-Camera instructions

### (Computer terminal)

## Chapter 1-----Introduction

Client software is used for realizing centralized monitoring, storage and control on video surveillance device of front-end network. The software supports 1/4/6/8/9/13/20/25/36 single-screen and full-screen display, two-way voice intercom, local video recording, picture capture, etc. Also, it is interface-friendly and easy to operate, thus facilitating users to realize remote network monitoring on multiple devices simultaneously.

### **Main functions:**

Real-time monitoring video image.

Support two-way voice intercom.

Support PTZ direction control, image rollovers and mirror image.

Support local manual video and Snapshot.

Support DDNS (Dynamic Domain Name Server) protocol.

## Chapter 2 -----installation guide

### 1. OS configuration requirements

Operating System: Windows 7、8/XP in English or simplified Chinese.

CPU: above P4 2.0G (suggested) .

Memory: above 256M.



Display card: support display card above DirectX8.1 , 32 M video memory.

Sound card: it is used to realize voice monitoring and two-way voice intercom.


Hard Disk: no less than 40G if you want to record video.


### 2. Software installation


#### 1.1 Find and open the installation program IPCMultiViewSetup



Click:




**1.2.** Click  to finish software installation




# Chapter 3 -----SoftwareInstructions

## 1. Main interface of the client





Open client program directly to enter into main interface as shown below: (User Name:admin Password:null)




1.The first time for using the client, users need to add IP address/device name to the client if they want to open the monitoring screen in LAN ,please following below steps:



1.1 Click  to pop up the following dialog.Open  (searching interface) and then click .Double click the searched IP address as follows:




1.2 Input a self-defined device name, Default username is admin, password (null),then click **OK** to finish.




2.Users can add P2P UID/device name manually if needed, Click as below.


then click **OK** to finish.



3.Select one in device list and **double click** it to the displayed window as shown below:



## 4. About :Motion Detection,Wifi,SDCard



## 5.Main interface function



: PTZ direction control



: Start "up/down" and "left/right" scanning.



:Image inversion



Auto connect all camera



Full screen




View video files




View Snapshot




Changen P2P Password



: open voice monitoring.



: Click Both to realize two-way voice between PC client and camera.



: Record local video.



: Snapshot( Click once to capture one picture).



: Multiple camera monitoring