

## 4-Channel Adjustable Line Output Converter | Part-No.: AA0418

Connect line output converter white wire (+) and white / black wire (-) to the front left speaker output of the source unit;  
 Connect line output converter gray wire (+) and gray / black wire (-) to the front right speaker output of the source unit;  
 Connect line output converter green wire (+) and green / white wire (-) to the rear right speaker output of the source unit;  
 Connect line output converter red wire (+) and red / gray wire (-) to the rear left speaker output of the source unit;  
 Connect line output converter brown wire to ground;  
 Connect line output converter yellow wire to +12v;  
 Connect line output converter black wire to power gnd;  
 Connect line output converter blue wire to remote turn-on for amplifier;  
 If there are two stereo minus, connect both line output converter minus wires to it. The rca cables are the output  
 For the line output converter 4 w / 3:1 step down w/adjustable control pots for the desired output. The brown wires are  
 Not usually used. The brown ground wires are to be used only if no sound is audible on both channels. Attach the  
 brown wires to the source unit's ground.

