digitech

400W Mini Fog Machine with RGB LEDs



User Manual AF-1225

Box Contents:

- 1 x Mini Fog Machine
- 1 x Wired Remote Control
- 1 x Mounting Bracket
- 1 x Mains Power Cable

Product Diagram:



#	Feature:	Description:
1.	Tank Cap	Unscrew to add the fog liquid to the tank
2.	Fog Liquid Capacity Level (Rear)	Shows the current fog liquid level left in the tank
3.	On/Off Switch (Rear)	Press to turn the unit on or off
4.	Wired Remote Control Socket (Rear)	Connect the wired remote control to this socket to operate the fog machine
5.	Mains Power Socket (Rear)	Connect the mains power cable to the power socket located on the rear of the unit and plug into a 240VAC wall socket
6	Nozzle	Sprays the fog out of the tank
7.	Adjustable Knob	Adjust the tightness for the mounting bracket
8.	RGB LEDs	Displays red, green and blue LED lights

Operation:

- 1. Position the fog machine on a flat surface.
- 2. Loosen the cap of the tank and add fog liquid up to 300ml.

Note: Only add high quality water based fog liquid; using low quality fog liquid may damage the unit.

- 3. Insert the mains power cable in to the rear power socket of the unit and the opposite end of the cable to a 240VAC mains wall socket.
- 4. Insert the wired remote control in to the rear wired remote control socket on the back of the fog machine.
- 5. Press the power switch to on for the unit to start heating up which will take up to 5 minutes.
- 6. The LED will turn on bright once the unit has heated up; you can now press the button to emit fog from the nozzle.

Note: After long burst of fog; the machine will require to heat up again. Wait until the LED lights up again to press the button.

Cleaning:

- 1. Clean the fog machine regular
- 2. Approximately every 40 hours of continuous use; it is suggested to clean the nozzle with 80% distilled water and 20% vinegar while operating. Disassemble the nozzle and use vinegar to clean it. Run in a well ventilated area until the tank is empty. Replace the nozzle and operate the unit with normal fog liquid.
- 3. Use dry cloths when cleaning the unit.

Safety:

- 1. Do not open the case of the fog machine to avoid damage and injury.
- 2. Keep the fog machine away from high temperatures as it may cause damage to the unit.
- 3. Do not expose the fog machine to water or liquids to prevent the unit from damage.
- 4. The unit must be installed in a well ventilated area.
- 5. Do not spray the fog machine directly at people.
- 6. Please leave 1m distance between other materials as the nozzle and top of the unit will get hot during operating.
- 7. It is suggested to remove all the fog liquid while transporting the fog machine.
- 8. This unit is for indoor use only.
- 9. It is suggested to use genuine water based fog liquid only as it may damage the unit long term.

Specifications:

Fog Output: 14m³/min

Spraying Distance: 3.5m

Heat Up Time: 5 Minutes

Tank Capacity: 0.3L

LEDs: 3 x 1W RGB

Power: 240VAC, 50-60Hz

Power Output: 400W

Dimensions: 250(L) x 140(H) x 130(W)mm

Distributed by: Electus Distribution Pty. Ltd. 320 Victoria Rd, Rydalmere NSW 2116 Australia Ph: 1300 738 555 Int'l: +61 2 8832 3200

Fax: 1300 738 500 www.electusdistribution.com.au