

Portable Stereo Speakers with Dock for iPod® and iPhone®

User Manual





Cover 封面 Inside-Cover 封二

Contents 1

Safety Precautions & Maintenance
Introduction
Overview 4
Getting Started 5
iPhone® & iPod® Docking 5
Battery Operation 6
Other Devices 6
Troubleshooting
Technical Specifications 8

2

Safety Precautions & Maintenance



Please read these operating and maintenance (servicing) instructions before installing and operating your speakers.

WARNING: To reduce the risk of fire or electric shock, do not expose this speaker system to rain or moisture (including swimming pools or objects filled with liquids, such as vases or drinks).

Important Safety Instructions

- Always read all Safety and Operation instructions before use.

 Retain instructions for later reference.
- 2. To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
- 3. Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain in a well ventilated area. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
- 4. Do not expose the speaker to extremely high or low temperatures.
- 5. Keep the unit away from direct sunlight.
- 6. Use only accessories and attachments as supplied and as designated in the instruction manual.
- 7. Do not attempt to open or modify the speaker in any way, as it does not contain any user serviceable parts. Please refer all servicing to qualified personnel.
- 8.The mains plug (power adapter) is used as disconnect device, the disconnect device shall remain readily operable.
- Always thoughtfully dispose of the packaging and the unit in accordance with the local regulations and in a responsible manner.

Introduction 3

Made for:

- iPod touch (2nd, 3rd and 4th generation)
- iPod classic
- iPod nano (3rd, 4th, 5th and 6th generation)
- iPhone 4S, iPhone 4, iPhone 3Gs, iPhone 3G, iPhone

Portable and versatile, these speakers are suitable for use in your bedroom, study or on the go. Dock your iPhone®/iPod® into the docking station to charge and enjoy high quality stereo sound from your device.


It even has a 3.5mm audio jack for use with all your other favourite personal media devices. Completely portable, the docking cradle tucks neatly into place to avoid damage and will operate on 4XAA batteries.

An AC/DC adaptor has been included in case you run out of juice and to use the speakers as a standalone charger.It's perfect for get-togethers with family and friends or for setting the mood on that perfect picnic date.

Please read through the user manual thoroughly before commencing operation of the unit.

4 Overview

- 1. iPod® Dock (pull down to open)
- 2. Power button
- 3. Volume +/- buttons
- 4. Battery compartments
- 5. Auxiliary input
- 6. DC Power Jack



Getting Started

5

To setup your iPod® speaker system, please follow these simple steps:

- 1) Carefully unpack speaker and power supply.
- Carefully unwind power supply cable and connect to the socket on the rear of the speaker unit. Connect the power supply plug pack to a suitable mains outlet.
- Place unit on a stable, flat, level surface out of direct sunlight.
 Always avoid leaving the unit in direct sunlight as this may cause damage.
- 4) To turn your speaker unit on, simply press the power button on the top of unit. The power indicator should glow.

iPhone® & iPod® Docking

To dock, charge and play your iPod® or iPhone®, please follow the following instructions.

- 1. Open the iPod® dock.
- Fit the iPod® carefully into dock, docking connector should easily connect with the socket on your iPod®. Please note: Do not force iPod®, but carefully slide over the dock connector as force may damage your iPod®.
- Turn speaker unit on, the iPod® should indicate that power is now connected.
- 4. Select your desired song.
- 5. Press play.
- 6. Volume can be adjusted by using the volume control buttons on the top of the unit.

NOTE: the product has a standard iPod® dock compatible with the Apple® dock insert supplied with your iPod® or iPhone®. To use dock insert, simply fit to dock on your speaker unit.

6

Battery Operation

The product will operate from a battery source for up to 3 hours when operated from Alkaline batteries (not supplied). Performance and sound quality may vary depending upon quality and age of batteries. We recommend Alkaline batteries for best performance. Do not mix battery types or old batteries with new. Do not leave batteries in unit for an extended period of time.

NOTE: unit will not charge your iPod® or iPhone® when operated from batteries.

Other Devices

To listen to an audio device via the Auxiliary Input please follow these instructions.

- Connect an audio source such as a third party MP3 Player, PC, CD Player or other audio source via the 3.5mm Auxiliary Input socket located on the rear of the unit.
- 2. Turn the unit on and use the +/- volume buttons to select the required volume.

NOTE: Connecting a plug into the 3.5mm "Aux" socket on the rear of the unit will bypass any audio from an iPod®/iPhone® docked on the top of the unit. The iPod®/iPhone® will continue to charge.

Troubleshooting

7

If you are experiencing problems with this speaker system, please try the following:

- Check the connection of the power cable to ensure that it is securely plugged into the speaker and the AC wall outlet and that unit is turned on. Alternatively, check that batteries are inserted and have available charge.
- 2. Check that the volume is turned up on the main unit.
- 3. Check that nothing is connected to the 3.5mm "Aux" socket.
- 4. Check that compatible iPod® is correctly inserted into dock.

Problem	Cause	Solution
No power	Power is not connected	Connect power and recheck
	Batteries are flat	Connect power or replace batteries
	Faulty Plug Pack powersupply	Contact seller for a replacement
No audio	Cable connected to the 3.5mm Aux socket	Unplug cable
	Unit not turned on	Turn unit on and recheck

8

Technical Specifications

Speaker unit

Output power: 2W rms x 2

Power supply: 110-240V ~ 50/60Hz Batteries: 4 x 1.5V AAA size - not supplied

Typical batteries operating time: up to 3 Hours playtime - Alkaline

batteries recommended for best performance Auxiliary input: 3.5mm stereo jack plug

"Made for iPod," and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod and iPhone, respectively, and has been certificated by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod or iPhone may affect wireless performance.

iPhone, iPod and iPod touch, iPod nano and iPod classic are trademarks of Apple Inc., registered in the U.S. and other countries.

Distributed by: Electus Distribution Pty Ltd 320 Victoria Rd Rydalmere NSW 2116 Australia Ph: 1300 738 555

Tax: 1300 738 500

www.electusdistribution.com.au

Made in China

%	F8	ひ奋达科技	时	间	2012-04-25	订单	单号	gm12081
品	牌		公司	型号	i212	客户	型号	AR1889
版	本	A 0	设计	内容	说明书	料	号	
<u>电</u> 软	<u>子</u> 件		<u></u> 结电	<u>构</u> 声		PLM文	档编号	
设计	者	叶春琼	标准	主 化		<u>项目</u> 产品	<u>经理</u> 经理	
复	核		业	务		核	准	

展			
AR1889 成型尺寸 150x105mm 対质要求 128G铜板纸 印刷要求 単黑印刷	gm12081	展开尺寸	150x105mm
印刷要求 单黑印刷	AR1889		
		材质要求	128G铜板纸
工艺要求		印刷要求	单黑印刷
		工艺要求	
页码数(页) 5页(页码数按成型尺寸计算页数)		页码数(页)	5页(页码数按成型尺寸计算页数)
i i			AR1889 成型尺寸 材质要求 印刷要求 エ艺要求