
## 5.8GHz AV Receiver

- 1. Connect power to the Receiver (RX)
- 2. Connect Receiver to the Display or Monitor you would like to view on.
- 3. Select the same channel that is used on the Transmitter to complete paring



	1	2	3
CH1	On	On	On
CH2	On	On	Off
СНЗ	On	Off	On
CH4	On	Off	Off
CH5	Off	On	On
СН6	Off	On	Off
CH7	Off	Off	On
CH8	Off	Off	Off