

## Set time:

When there is clock mode, long press SET TIME button for 2 seconds to set time, press TU+/MIN button set minute, press TU-/HOUR button set hour.

## Choose 12/24 clock setting

Then, short press SET TIME button can set 12/24 clock, Press TU+/MIN, TU-/HOUR to choose 12 or 24 clock.

## Set day of week

Then, short press SET TIME button to set day of week (from d1 to d7), press TU+/MIN, TU-/HOUR to change the day.

Press SET TIME again to finish all time setting.

When you finish setting, you can short press SET TIME to check day of week.

\*You only can set the time on this order: time > 12/24 clock > day of week

## Set alarm 1 / alarm 2

### Alarm 1:

When there is clock mode, long press VOL-/ALM1 for 2 second to set alarm 1, press TU+/MIN to set minutes, press TU-/HOUR to set hour, then short press to set the alarm period, you can choose 1-7, 1-5, 6-7. Short press again to finish setting.

You can short press VOL-/ALM1 to choose alarm to bells / alarm to radio / off alarm.

### Alarm 2:

When there is clock mode, long press VOL+/ALM2 for 2 second to set alarm 2, press TU+/MIN to set minutes, press TU-/HOUR to set hour, then short press to set the alarm period, you can choose 1-7, 1-5, 6-7. Short press again to finish setting.

You can short press VOL+/ALM2 to choose alarm to bells / alarm to radio / off alarm.

\* In alarm to bells mode, alarm will keep ring continuously about 45 seconds if no any action on it, then stop, after 9 minutes will ring again.

Turn off alarm:

When the alarm is ringing, you can press ALM OFF button to turn off the alarm.

## SNOOZE:

When the alarm is ringing, you can press SNOOZE button to stop it, it will ring again after 9 minutes.

## Use Radio:

Press POWER button to turn on, long press TU+/MIN or TU-/HOUR button for 2 seconds to auto search channel. Short press TU+/MIN or TU-/HOUR button to adjust the frequency you want.

## Auto save channel:

The device can auto save 20 channels, long press MEMORY button, it will auto search and save 20 channels from P01 to P20 (The channel search result depends on the strength of signal). When finish setting, short press MEMORY to choose channel.

When you are in radio mode, press VOL+/ALM2 button to increase volume, press VOL-/ALM1 to decrease volume.

## DIMMER:

When there is clock mode, press DIMMER button to adjust the brightness.

## Sleep:

You can use sleep mode to set time to turn off radio, press SLEEP button, you can set the sleep time from 90 mins to 10 mins.

## Use USB for charging

You can use USB slot to charge the device, output is 5V 1A (depend on the adapter you use).

**\*Please alert the SNOOZE button at the bottom when you are doing setting, don't keep press it when doing setting.**