

RESPONSE

User Manual

Bluetooth Handsfree with FM Transmitter

AR-3132



FEATURES:

- Wirelessly transmit phone calls from Bluetooth® mobile phone to the car FM stereo system.
- With A2DP Bluetooth®, wirelessly play music from a Bluetooth® mobile phone to car stereo
- Built-in microphone.
- Built-in FM transmitter, full frequency: 87.5-108MHZ.
- Supports USB flash drive and MicroSD card.
- With 3.5mm line-in jack, supports external audio devices.
- USB charging port for charging mobile phones and other devices (output: DC 5V/1A).
- Support 12-24V input.
- Support multiple languages.
- LCD screen display.
- Infrared remote control.

SPECIFICATIONS:

- Power: 12/24VDC
- USB output: 5V 1A
- Aux input: 3.5mm
- Built-in mic
- Bluetooth class: V2.0
- Frequency range: 87.5 - 108MHz
- Dimensions: 87(L) x 39.39(W) x 19.5(D)mm

DEVICE:

1 – Answer Call

4 – Play/Pause

7 – Hang up

2 – Previous/Volume Down

5 – AUX In

8 – MicroSD Card Slot

3 – Next/Volume Up

6 – USB Charging Port



QUICK GUIDE:

Operation Guide	On FM transmitter	On Remote Control
Answer/Hang up a Call	Press "Answer Call" button: answer the call Press "Hang Up" button: hang up the call	Press "☎" to answer the call Press "☎" to hang up the call
Play and Pause the Music	Press "▶/ " Button: Play the music Press "▶/ " Button again: Pause playing	Press "▶/ " Button: Play the music Press "▶/ " Button again: Pause playing
Adjusting the Volume	Press and hold "▶▶" button: Increase Volume Press and hold "◀◀" Button: Decrease Volume	Press "+" to increase the Volume Press "-" to decrease the Volume
Setting the Frequency	Press "CH" button first, then: Press "▶▶": increase the frequency Press "◀◀": decrease the frequency	Press "CH+" button: Increase by 0.1MHz Press "CH-" button: decrease by 0.1MHz OR Press the numbers of the frequency that you want and press "CH+" to confirm
Choosing the Music	Press "▶▶" Button: Play the next song Press "◀◀" Button: Play the previous song	Press "▶▶" button: Play the next song Press "◀◀" button: Play the previous song OR Press the number of the song you want and press "▶/ " to confirm
Choosing the EQ	Not Supported – Can only be done on the Remote Control	Press "EQ" button to change the EQ
Changing to a different Folder	Press "▶/ " button first, then press and hold "CH" button to get to the menu list, use "▶▶" and "◀◀" to scroll, and 'CH' to select the desired folder	Press "Folder" button to switch folder
Making a Call	Not Supported – Can only be done on the Remote Control	Press "☎" button, input mobile number on the remote control, then press "☎" button again

USING THE FM TRANSMITTER FUNCTION:

1. Plug the FM transmitter into your vehicle's cigarette lighter or power port.
2. Tune your radio to an unused FM frequency, then match the same frequency of this unit.
3. Insert a USB flash drive or Micro SD card which contains MP3 files into USB port or memory card slot of the unit. It will play and transmit the MP3 files automatically.
4. Line-in function: Use the provided audio cable to connect an external audio source to the AUX input of this unit. When using this function, please stop playback of USB or memory card, and all functions will be controlled by the external audio source.

USING THE BLUETOOTH® FUNCTION:

1. Using Bluetooth® for the first time, you need to pair your mobile phone with this unit. Activate your mobile phone's Bluetooth® function, then search for a new device. When the mobile phone detects this unit (named as "AR3132"), please pair and connect by using the original password "0000" if prompted.

Note: Password may vary depending on your phone model and make. Please refer to your mobile's user manual for further information should the password '0000' not be accepted.

2. In the music playing mode, when there is an incoming call this unit will automatically switch to telephone mode.
3. After the Bluetooth® has been connected with the mobile phone, it supports playing music from the mobile via Bluetooth® to your vehicle's speaker.

Note: The Bluetooth® icon which is displayed on the unit screen will stop flashing after the Bluetooth® is connected with your mobile phone.

BLUETOOTH® CALLING:

- Please press the green "**Answer**" button on the front of the transmitter to answer the incoming call.
- Please press the red "**Hang up**" button on the top of transmitter to hang up a call.
- When making a call, you can only dial the phone number on your mobile phone or from the remote control, but once the call is connected you can talk freely.

USING THE USB CHARGER FUNCTION:

When this unit is powered from car lighter socket, connect the USB port of this unit to your mobile phone with a USB cable (not included). This unit will serve as mobile phone charger.

MENU SETTING:

When the unit is playing from an USB flash drive or Micro SD card, you can follow the below instructions to change the settings (only from the FM Transmitter, not supported from the Remote Control):

1. Press "▶/||" button to pause the music.
2. Press and hold "CH" button to access the menu list, use "▶▶" and "◀◀" to scroll and "CH" to enter:
 - * Language – Enter to change the user language
 - * Contrast – Enter to change the LCD contrast
 - * Firmware version – Enter to view the firmware version
 - * Exit

Distributed by:

TechBrands by Electus Distribution Pty. Ltd.

320 Victoria Rd, Rydalmere

NSW 2116 Australia

Ph: 1300 738 555

Int'l: +61 2 8832 3200

Fax: 1300 738 500

www.techbrands.com