


2.4GHz Remote Control Bug

User Manual

GT-3075

Batteries:



Operation:

1. Insert 3 x AAA batteries (not included) in to the battery compartment located at the bottom of the R/C bug and 2 x AAA batteries in to the battery compartment of the remote control.
2. Turn the power switch to on for the remote control and then the bug. You can now operate the bug.

Note: Works best on a flat and hard surface; may not run as fast on smooth or slippery surfaces.

Specifications:

Frequency: 2.4GHz

Remote Control Range: 15m

Play Time: Up to 1-2 Hours

Batteries:

Bug: 3 x AAA (Not Included)

Remote: 2 x AAA (Not Included)

Dimensions: 175(L) x 110(W) x 80(H)mm