



表紙(カラー)

Balloon Helicopter Instructions

- Attach propeller blades A to hub B.
- Pull the balloon up until this dotted line to attach it. (Do not confuse the orientation of C.)
- After inflating the balloon through C, pinch the neck of the balloon to keep the air from escaping prematurely.
- Attach C to B.
- Face the propeller blades toward the sky. Toss the balloon upward to begin its flight. It should soar upward while making noise.

⚠ WARNING

- CHOKING HAZARD—Small parts. Not for children under 8 yrs. Children can choke or suffocate on uninflated or broken balloons. Adult supervision required.
- Keep uninflated balloons away from children. Discard broken balloons at once.
- Store this product away from direct sunlight and high temperature.
- NEVER fly this towards people.
- Keep away from open flame and other heat sources. Do not overinflate the balloon.
- Do not inhale or put any of this product into your mouth.
- Do not play with this product near electric cables / wires, rail tracks, roads, or airports.
- If by any chance this product gets accidentally tangled in electric cables / wires, please do not try to remove it on your own. Call your local utility company.
- Keep this product away from sharp objects.

Materials / Polypropylene, Polyethylene, Polyvinyl chloride, Rubber



⚠ WARNING



CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963

K1212
MADE IN CHINA

裏紙(一色)