



24HR Mechanical Mains Timer MS-6109 User Manual

POWERTECH PLUS

Please read the following instructions carefully before connecting this timer to electrical appliances.

OPERATION INSTRUCTIONS

1. Turn the dial clockwise until the pointer is at the current time.
2. Press down the pins according to the “on” duration(s) required. To cancel an “on” time, lift up the pin(s) again. For example, to switch on from 8:00AM to 8:30AM: Press down pins between 8:00 and 8:30. There are 96 pins, each for setting a 15 minute interval, which adds up to 24 hours.
3. To activate the timer function, make sure the timer/manual switch is slid to the left. To disable the timer function, slide switch to the right.
4. Plug the timer into wall outlet and then plug required appliance into the timer. (You must plug the timer into as soon as possible after setting the time pointer, otherwise the timer clock will be slow).
5. Turn on appliance as normal. (NOTE: appliances that require pressing a button as well as applying AC power will not work with this timer).
6. For outdoor use, observe conditions as below:
 - A. If the timer is plugged into portable socket outlet device, the socket must be positioned vertically
 - B. With no appliance plugged into the timer, the transparent cover must be able to close.

SPECIFICATIONS

Power Rating: 240VAC @ 10A / 2400W
Max. IP Rating: IP44
Weight: 165g
Dimensions: 79(W) x 91(H) x 75(D)mm

Distributed by: TechBrands by Electus Distribution Pty. Ltd. 320 Victoria Rd, Rydalmere, NSW 2116 Australia
Ph: 1300 738 555 Int'l: +61 2 8832 3200 Fax: 1300 738 500
www.techbrands.com Made in China

