

Rave

LED Move DMX Flash Light



SL-3484
User Manual

Box Contents

- 1 x LED Move DMX Flash Light
- 1 x Power Supply
- 1 x Remote Control

1. Function control

1.1 Function buttons

MENU: Press to change and select from 1 of 10 available functions (including DMX function).

UP/DOWN: Adjust each functions speed.

ENTER: Save the mode you prefer for start up. If not press ENTER to reset.

2. DMX 512 mode

Display will show A001 – A512:

This mode requires the unit to be connected to a DMX512 controller. After powering up, turn on the first channel of the DMX mode. The DMX mode has 7 channels which need to match up with the DMX controller.

| Channel | Value | Description |
|---------|---------|--|
| CH1 | 0-7 | Switch |
| | 6-255 | Strobe from fast to slow |
| CH2 | 0 | Red off |
| | 1-255 | Gradual change from dark to light |
| CH3 | 0 | Green off |
| | 1-255 | Gradual change from dark to light |
| CH4 | 0 | yellow off |
| | 1-255 | Gradual change from dark to light |
| CH5 | 0-10 | Motor stop |
| | 11-255 | Strobe from slow to fast |
| CH6 | 0-127 | Motor stop |
| | 128-255 | Motor reverse |
| CH7 | 0-9 | Chan1-6 |
| | 10-39 | A1 |
| | 40-69 | A2 |
| | 70-99 | A3 |
| | 100-129 | A4 |
| | 130-159 | A5 |
| | 160-189 | A6 |
| | 190-219 | A7 |
| | 220-249 | Sound Activation(lights off)-No function adjustments available |
| | 250-255 | Sound Activation(lights on)-No function adjustments available |

Manual of remote controller

POWER ON / OFF
Through the keys into the DMX mode and exit the DMX mode

SUSPEND STARTUP MODE
Through this button pause and restart

FLASH MODE
Set up automatic flash, - + key blasting flash speed can be adjusted

MENU OF MODES
switching effects and functions by choosing A1,A2,A3,A4,A5,A6,A7

DMX START OFF MODE
Through the keys into the DMX mode and exit the DMX mode

SOUND ACTIVE MODE
How quickly along with the music rhythm changes, Flash acoustic control, blasting button MUSIC1 MUSIC2 dynamic voice control, MUSIC3 lyric voice control, switching between different effects

MOTOR ROTATION, FLASH ADJUSTMENT MODE
- + Between 1-9 keys to adjust electric machine rotating speed and critical speed

Technical Parameters

| | |
|-----------------|----------------------|
| Light source | 9X1W |
| Source lifetime | Rated 200,000 hours |
| Power supply | 100-240V/50-60HZ |
| Rating power | 10W |
| Effect | LED light move flash |

Feature set

| Mode | Function | Value | Content |
|------------|-------------------------|-------|--|
| A1 | AUTO | 1-9 | Red & Yellow on, motor moves slowly to speedy |
| A2 | | | Green & Purple on, motor moves slowly to speedy |
| A3 | | | Blue & white on, motor moves slowly to speedy |
| A4 | | | 6-color changing, motor moves slowly to speedy |
| A5 | | | 7-color changing, motor moves slowly to speedy |
| A6 | | | color changing slowly 1, motor moves slowly to speedy, no strobe |
| A7 | | | color changing slowly 2, motor moves slowly to speedy and strobe |
| S1 | SOUND | 0-20 | In sound, color change, blasting flash mode |
| S2 | | | Sound, color change, the dynamic mode |
| S3 | | | Sound, color change, lyrical mode |
| Stop Start | Stop and Start | | Through this button pause and restart |
| FLASH | FLASH | | Automatic flash explosion, through the key - + blasting flash speed can be adjusted, |
| DMX | BOOT OFF | | Through this key into the dmx mode and exit the dmx mode |
| - + | Flash speed Motor speed | | Through this key to adjust motor rotation speed and the critical speed |

Attention

- Please read these operating instructions carefully to familiarise yourself with the basic operations of this unit BEFORE USE.
- Unless the instructions have already stated, please do not freely modified the unit.

Safety Tips

- Before installation and maintenance, please confirm the power is OFF, make sure that the ventilation around the unit is good.
- The lighting is designed for indoor demonstration, please do not use this product in a wet environment for long-term.
- The use and maintenance of this unit should avoid contact with water, when using it outdoor, please take waterproofing measures.
- Personnel, who undertake the installation, operation and maintenance, must be familiar with the lighting performance. Damage may result from misuse.
- Do not face up to the luminous unit for a long time, so as not to cause discomfort to your eyes.
- To keep clean, wipe the unit with a clean cloth.

Distributed by:
TechBrands by Electus Distribution Pty. Ltd.
NSW 2116 Australia
Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500
www.techbrands.com