

## Directions for Use


Installation of the remote control (see picture 1). When the remote control is mounted correctly on the bicycle handle basr, the two red LED' s should be on the top and the 3 push buttons are on the bottom.

Installation of the signal pod unit (see picture 2) under the bicycle seat on the metal shaft facing backwards. Power on the unit by pressing the red button on the back side of the unit. This main unit cannot be powered on if the UP triangle in the front side of the unit is not pointing upwards. Once it is powered on, the red LED inside the UP triangle will act as a power indicator and will flash continuously unless the arrows are flashing.

When making a left turn, please press the left button on the remote control once. The left arrows inside the main unit and the red LED on the left side of the remote control will flash. The buzzer also will sound. To turn off, please press the left button of remote control again.

When making a right turn, please press the right button on the remote control once. The right arrows inside the main unit and the red LED on right side of the remote control will flash. A different buzzer sound will be heard. To turn off, please press the right button of the remote control again.

For Hazard lights, please press the hazard button in the middle of the remote control. Both the left and the right arrows will then flash together. Please press the hazard button again to turn the arrows off.



**PICTURE 1.**

Align and slide the remote control onto the mounting base. Press the lever and slide the remote control out of the mounting base.



**PICTURE 2.**

Align and slide the main unit onto the mounting base. Press the lever and slide the flashing arrow unit out of the mounting base.

## Changing the battery

To replace the battery in the remote control, please turn and remove the battery cover (see picture 3). Remove the existing CR2032 battery from the compartment. Insert a new battery there with the positive (+) facing up. Then close the battery cover according to the arrow on the door.

To install or replace the batteries in the main unit, please unscrew the battery cover that goes together with the mounting bracket (see picture 4). Remove the 3 x AAA batteries(not included) from the compartment and insert three new batteries according to the battery orientation inside the compartment. Then screw on the battery cover and mounting bracket. Please note the battery cover can only be screwed on in one orientation and cannot be reversed..

**PICTURE 3**



**PICTURE 4**

