

protech

30W Hot Glue Gun

HOBBYIST



User Manual



Please read and save all instructions to ensure safe and effective use of this product.

TH1997

CONTENTS:

General Information & Safety Instructions	3
Box Contents	3
Overview	3
Before First Use	4
Operating Instructions	4
Cleaning, Care, Storage & Maintenance	5
Troubleshooting	5
Specifications	5
Warranty	6

GENERAL INFORMATION & SAFETY INSTRUCTIONS:

- Do not use near flammable gas or liquid.
- Do not shake or drop the Glue Gun.
- Do not leave the Glue Gun unattended when unit is powered.
- Ensure the Glue Gun has been left unplugged and had time to cool down before storage.

WARNING: The manufacturer is not responsible for any potential injury from misuse.

NOTE: For intermittent use only. Not for production use.

BOX CONTENTS:

- 1x Glue Gun
- 2x 7mm Glue Sticks
- 1x User Manual

OVERVIEW:



BEFORE FIRST USE:

Prior to using your product, please read all the safety and operating instructions thoroughly. Please ensure you follow the steps below before using the product. We recommend you keep the original packaging for storing the product when not in use.

Please pay close attention to the section entitled Important Safety and General Instructions. Find a safe and convenient place to keep this instruction manual for future reference.

Unpack the product but keep all packaging materials until you have made sure your new product is undamaged and in good working order. Ensure you have all accessories listed in this manual. Plastic wrapping can be a suffocation hazard for babies and children so ensure all packaging materials are out of their reach.

WARNING: Before each use, clear the glue stick rear entry to ensure the area is free of remaining glue from previous use.

WARNING: Before use, check the power cable to ensure it is free from any damage.

OPERATING INSTRUCTIONS:



1. Insert a 7mm glue stick into the rear entry glue stick holder.

2. Press the trigger gently until resistance is felt to ensure the glue stick is installed correctly



3. Connect the unit to a mains outlet.

4. Pre-Heat for 4 to 8 minutes.



5. Press the trigger gently and the glue will flow out from the nozzle.

CLEANING, CARE, STORAGE & MAINTENANCE:

- Clean any remaining glue out of the glue gun after use.
- Ensure the Glue Gun has been left unplugged and had time to cool down before storing the glue gun.

WARNING: The glue gun must be left for at least 10 minutes unpowered before touching the nozzle to avoid injury.

TROUBLESHOOTING:

Problem	Solution
Glue is not flowing from nozzle	<ul style="list-style-type: none">• Check power is turned on.• Ensure nozzle is clear of any blockages.
Glue gun is not heating up	Return to place of purchase to replace under warranty.

SPECIFICATIONS:

Input:	220 – 240V
Rated Output:	30W at 240V
Compatible Glue Stick:	7mm
Dimensions:	117 x 117 x 25 mm
Weight:	157g

WARRANTY:

Our product is guaranteed to be free from quality and manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim. Should you not be able to provide proof of purchase with a receipt or bank statement, identification showing name, address and signature may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution
46 Eastern Creek Drive,
Eastern Creek NSW 2766
Ph. 1300 738 555