

## 3.5mm Plug to Plug Lead with Microphone & Volume Control

WA-7122



### A:

**Play/ Pause:** Press once to play or pause the current music track.

**Call/Hang Up:** Press once to answer an incoming call or press to hang up the current call.

**Next Track:** Press twice to skip to the next music track.

**Previous Track:** Press three times to skip to the previous music track.

### B:

**Volume Slider:** Move up or down to change current volume.

### Headphone Connection:

**4 Pole:**  
Connect to  
Device



**3 Pole:**  
Connect to  
Headphones

