

If the photos are not visible, please check the photo formats to see if they are correct. Currently the iPad® supports JPEG, TIFF and GIF image formats.

Note: If you are transferring images onto a SD card or USB drive from your computer, you must create a folder named "DCIM" in order for the photos to be visible otherwise the photos will not be seen. A folder named DCIM may already be visible if the SD card has been used on camera.

Note: Only photos with the original name can be recognised such as "IMG_****" or "DSC_****". Please keep the original file name as it will not be recognised.



4



6 in 1 iPad® Card Reader




User Manual

1. Connect your card reader to the socket of your iPad®.



2. Use the switch on the right hand side of the device to switch between USB for USB flash drives and card for SD card use. Photos from your digital camera, USB flash drive or SD card can be directly imported onto your iPad®.



2

3. Once your digital camera, USB flash drive or SD card has been connected, it will display the album on your iPad® for it to be imported. You can import individual or all photos if required.

Note: Depending on the power consumption, some keyboards may not work when plugged into the card reader.



3