



DIGITECH

User Manual

Slimline LCD Clock With Thermometer

XC-0230



Distributed by:
TechBrands by Electus Distribution Pty. Ltd.
320 Victoria Rd, Rydalmere
NSW 2116 Australia
Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500
www.techbrands.com

Specifications:

Time Display:	12/24 hour selectable
Temperature Display:	°C/°F selectable
Digit height:	35mm
Temperature Range:	0°C-50°C (calibration time: 30 seconds)
Power:	2 x AAA batteries (not included)
Dimensions:	215(L) x 73(H) x 22(D) mm

Instructions:

- Open the battery compartment and insert 2 x AAA batteries in the correct polarity.
- Press and hold down the 'SET' button for 2 seconds, the hour display will start to flash.
- Use the '▲' and '▼' buttons to set the correct hour, press 'SET' to confirm the setting.
- The minute display will start to flash, use the '▲' and '▼' buttons to set the correct minute and press 'SET' to confirm the setting.
- The setting up procedure is now complete and the clock is ready for use.

- To change between 12/24 time format, press the '▲' button to switch between the modes. In 12-hour format, the AM and PM symbols will appear on the display with the time.

- To change the temperature between Celsius and Fahrenheit, press the '▼' button to switch between the modes.

NOTE:

- When the LCD display becomes dimmer, please replace the batteries.
- Only use AAA batteries in this timer.
- Ensure not to mix old and new batteries.
- Please dispose of used batteries in a responsible manner.
- Never attempt to open, modify or repair the clock in any way.
- Never get the clock wet.