



GAMERTECH

USB Gaming Keyboard



User Manual

XC-5130

Setup:

Colour & Brightness:

Turn LED Backlight ON/Off: FN + Scroll Lock

Breath & Static Mode: FN + Pause Break

Adjust Brightness:

Increase: FN + PaUp (Page Up)

Decrease: FN + PaDn (Page Down)

Macro Keys:

Set Macro Key:

1. Press the "REC" key located on the top left of the keyboard, the "SCROLL LOCK" key will flash slowly.
2. Press the "G1-G5" macro keys located on the left hand side of the keyboard, choose which key you would like to use for this macro.
3. Press the combination keys that you would like to use for this macro, for example you could choose "CTRL+1".
4. Press the "REC" key to complete the settings.
5. Now you will be able to press the "G1-G5" keys depending on which you have selected.

Note: The macro keys will automatically save in the keyboard even if the keyboard is used on another computer.

Cancel Macro Keys:

1. Press the "REC" key, the "SCROLL LOCK" will flash slowly.
2. Press the macro key you would like to cancel such as "G1-G5", the "SCROLL LOCK" will flash fast.
3. Press the "REC" key to complete the setting.

Specifications:

Macro Keys: 5

Multimedia Keys: 8

Key Number: 118

Backlit Colour: Dark Blue, Light Blue, Green, Red, Purple, Yellow, White

Compatibility: Windows 10, 8.1, 8, 7, Vista, XP, 2000, Mac OS X® 10.0+,

Linux

Weight: 855g

Dimensions: 488(L) x 223(W) x 34(H)mm

Distributed by:

TechBrands by Electus Distribution Pty Ltd

320 Victoria Rd, Rydalmere

NSW 2116 Australia

Ph: 1300 738 555

Int'l: +61 2 8832 3200

Fax: 1300 738 500

www.Techbrands.com

Made in China