


Rechargeable Speaker w/ MP3 Player




USER MANUAL

MODEL: XC5176

— Please read this manual carefully before using. —

ICON AND FUNCTION EXPLANATION



ICON AND FUNCTION EXPLANATION

- This digital speaker can be deemed as perfect combination of classic and modern performance, and it is praised as masterpiece of audio boxes.
- New mini aluminum vibration film loud speaker, which has clear alt and pure woof. The unique design makes tone performance perfect.
- Mini audio box with new concept integral stereo portable mobile music, connecting your MP3, MP4, CD, DVD, iPod, iPhone, GPS, PSP, mobile phone, notebook computer, Micro SD/TF card, etc.

— 1 —

- Metallic shell shows noble and fashionable, out of ordinary, with many colours, several solutions; for your option.
- Several power supply manners including battery, computer USB, adaptor DC-5V allow you to enjoy the charm of digital products at any time.

SPEAKER'S FUNCTIONAL PARAMETER

- Output: RMS 6W (3W+3W) THD=10%
- Frequency response: 150-18000HZ (±3dB)
- Signal and noise ratio of power amplifier: ≥80dB
- Loud Speaker 1.77 inches (external diameter 45mm) Magnetic resistant 4Ohms
- Power supply: 5V/1000mA AC power adapter, computer USB power rotate connect line (can choose)

USE EXPLANATION

- Battery: built-in Lithium battery, can play music and charge when use USB power.
- DC-5V: Direct current 5V (0.4A-1A) power adapter, use USB power supply
- OFF/ON: On-off set to OFF then already close power supply, set to ON then audio by merit exportation
- MICRO SD: Put TF card or Micro SD card into this hole.

— 2 —

- Charging: Use computer USB power or DC-5V adaptor as power supply and charge, when power off, indicator light turns red while charging, once charging completes, the light turns off; When power on, indicator light turns pink while charging; if power on but not charging, indicator light turns blue.

Special Prompt

- XC5176 functions as MP3 decoding, capable of directly inserting the Micro SD/TF card for playing music. It is the optional MP3 mate for Micro SD/TF card.
- For playing, Stop key, VOL- for volume down by steps, and VOL+ for volume up by steps.
- Last music and next music
- JH-MD05 can decode the MP3 format music play.
- When the Micro SD/TF is directly inserted, music will be played in the least volume. Now you can press VOL+ to turn up volume.
- Default mode is Line In mode, Insert Micro SD/TF card it will change to Micro SD/TF mode automatically to play music.

— 3 —