



Bluetooth® Game Controller for Android & Windows



User Manual
XC-5800


Box Contents:

- 1 x Bluetooth® Game Controller
- 1 x USB Charging Cable

Product Diagram:




Android Direct-Play Mode Instruction



Operation Instruction:

- 1 Press [HOME] button to Power on gamepad ;
- 2 Press [X+ANDROID] buttons till [LED3] indicator flashes fastly into pair status of Direct-Play mode;
- 3 Turn to the [Setting Panel] to turn on [Bluetooth] to start search services;
- 4 Few seconds later get the device list of [XC-5800] , click to pair and connect;
- 5 [LED1] indicator is long on while bluetooth connect successfully. (Detailed information is in accordance with the final)




Add or Edit on Android

The gamepad is with built-in memo chip saved setting data for 4 games, if you want to revise settings, follow these steps:

- 1.Log in Google Play Store to download the app "ShootingPlus" and install it to you android mobile/tablet pc.
- 2.Open the floating window for "ShootingPlus".
- 3.Connect the controller to your android device.Open the App.
- 4.Enter the game,press " START "Button on the controller to release the keymapping menu as below photo on PUBG mobile.
- 5.Move the buttons to the position of the correspondence virtual buttons as your style.
- 6.Tap "SAVE" the settings and close it to enjoy your games.



7.Reset the default setting data: Open the app-Tap the icon ⚙️ on the right corner-Restory-OK



Note:Please forget the device and reconnect after resetting the data.

Sleep mode & re-connect


Without any operation, 5-10 minutes later, the gamepad will turn into sleeping mode.Press the [HOME] button shortly, the gamepad will power on and connect the device automatically. (Paired and connected at last time)

Note:
The bluetooth function on the device must be kept on-state.

Power Off


Press the [HOME] button 3-5 seconds, all indicators black out, the gamepad power off.

Android HID Gamepad Mode Instruction



Operation Instruction:

- 1 Press [HOME] button to Power on gamepad ;
- 2 Press [X+ANDROID] buttons till [LED3] indicator flashes fastly into pair status of HID Gamepad mode;
- 3 Turn to the [Setting Panel] to turn on [Bluetooth] to start search services;
- 4 Few seconds later get the device list of [XC-5800] , click to pair and connect;
- 5 [LED3] indicator is long on while bluetooth connect successfully. (Detailed information is in accordance with the final)



Android HID Gamepad Games

For android system,the bluetooth gamepad can support the games which support HID gamepad.Also,we can use another game assistant software to keymapping the buttons on APK to control the game with gamepad.

- 1.Search "Octopus" on playstore,click to download to your cellphone or scan the QR code to download the assistant software.



Scan to download Octopus

Scan the QR code to download the game APK which collect the android games support gamepad.



Specifications:

Bluetooth® Version: 4.2+EDR
Transmission Range: Up to 10m
Compatibility: Android 5.0+
Windows (Bluetooth® Required)
Supported Phone Size: 4-6"
Play Time: 8-10 Hours
Charge Time: 2.5-3 Hours
Battery: 3.7V Li-ion, 350mA
Power: 5VDC, 500mA
Dimensions: 160(W x 105(D) x 55(H)mm

Button List:

Arena of Valor, Mobile Legends default buttons			
Function	Button	Function	button
Movement	Left Joystick	Recall	R1+L1
Purchase up	UP	Restore	R1+L2
Purchase Down	Down	Summoner Talent	R1+R2
Add talent 1	Left	Map	Right Joystick
Add talent 2	Right	Attack	R1+X
Add talent 2	R3/Press Right Joystick	Retreat	R1+Y
Basic Attack	A	Gather	R1+B
Push Tower	B	Shop	R1+UP
Last hit	X	Talent 2	L2
Match information	Y	Talent 3	R2
		Talent 1	L1

PUBG Mobile, Knives Out default buttons			
Function	Button	Function	button
Movement	Left Joystick	Free look	L1
Pop head Left	R1+Left	Jump	A
Pop head right	R1+Right	Get down	X
Weapon 1	Left	Crouch	B
Weapon 2	Right	Load shot	R1+R2
Take medicine	L3 (Press Left joystick)	Run	R1+Y
Hand Grenades	R3	Bag	R1+A
Nearby objects	R1+X	Map	Y
Pick up objects	UP	Fire	R2
Drive	R1+UP	Open Scope	L2
Ride	R1+L2	View angle	right Joystick
Get off	R1+Down		
Open door/Rescue	Down		

Distributed by:
Electus Distribution Pty. Ltd.
320 Victoria Rd, Rydalmere
NSW 2116 Australia
Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500
www.techbrands.com