


QUICK START GUIDE


AC1200 Whole Home Wi-Fi Mesh System



WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)

HALO BASE PRO To form mesh system, you need to purchase extra devices of the same series.

OVERVIEW



- 1 LED Indicator
- 5 Reset button
- 2 Touchlink sensing area
- 6 Pair button
- 3 Power port
- 7 Internet LAN/Backhaul
- 4 OFF/On button
- 8 Gigabit LAN port

Pair Button:
Press and hold for 2 seconds to add an extra mesh device to the existing Wi-Fi system.

Reset Button:
Press and hold for 6 seconds to reset the mesh device.

01

LED INDICATION


Router Mode	LED	Description
Router Mode	Solid purple	The device is being activated.
	Solid blue	The Internet is connected.
	Blue flash	1. Touchlink is in progress. 2. Router mode device is being paired with other mesh devices.
	Slow Red flash	No access to the Internet.
Extender Mode	Blue flash	1. Touchlink is in progress. 2. Mesh device is being paired with router mode device.
	Fast Red flash	The device is disconnected.

BASIC INFO

Default IP: 192.168.10.1
 Default Password: admin
 Login: <http://wifi.wavlink.com>
 Mesh SSID: [WAVLINK_XXXX](#)
 Touchlink SSID: [WAVLINK_Touch](#)
 Official Website: www.wavlink.com
 Technical support: support@wavlink.com


02

WiFi Configuration


- Select one of mesh devices as your router, connect its **Internet LAN/Backhaul** to the modem, then plug it in a power outlet.
 
- Connection

2.1 Via Wireless



Turn on your Wi-Fi, search SSID "WAVLINK_XXXX", and connect to it, then you can start configuring.




2.2 Via Cable




Connect Ethernet cable to your PC/laptop and device LAN port, then you can start configuring.


03
- Launch a browser from your laptop/PC or smart phone and enter wifi.wavlink.com or 192.168.10.1 in the address field. The default password is **admin**.
 
- Select your **Region**, for your network security, we suggest you set a new login password following the rules accordingly.
 

04
- Then you'll be led to "**Wizard**" page for further configuration.
 

Note: You can change Wi-Fi SSID if you want to.


Which WAN Type am I supposed to choose?
 If you use DSL line and you are only provided an account name and a password by your ISP, choose **PPPoE**. If you use cable TV or fiber cable, choose **DHCP(Dynamic IP)**. If you are provided information such as IP address, Subnet Mask and Default Gateway, choose **Static IP**.

05
- Please wait patiently for the process to complete, then you can enjoy your wireless network.
 

06
- After configuring the main router, now you need to set up other mesh devices as extenders/satellites: other mesh devices will detect the main router on their own, so you only need to plug in the other one/two (it depends on which kit you bought) device(s), they will act as mesh extenders automatically.
 

07


LAN BACKHAUL

- If your wireless signal weakens because of complex environment, you can try the second option **LAN Backhaul**.
 
- Connect the "Internet LAN/Backhaul" port of the extender to "LAN" port of your router.

08

TOUCHLINK TECHNOLOGY

Touchlink is the patented technology of Wavlink. At the top of the mesh device there is the Touchlink sensing pad; once you touch the pad with your hand or other devices, the sensing pad will blink blue, indicating that Touchlink is in process, then you can search "WAVLINK_Touch" and connect to it without any password.




Note:
Touchlink works for smart phone, tablet computer, laptop, etc.

09

FIRMWARE UPGRADE

If you need to update firmware, please proceed as the following steps:

- Download the latest firmware file on Wavlink website.
- Extract the firmware from the downloaded file.
- Log in to 192.168.10.1 or wifi.wavlink.com, then choose "Setup" and select "Upgrade Firmware".



10


- Click on **Browse** to locate the extracted firmware file.
- Click on **Apply** and wait for the firmware upgrade process to complete.

What is firmware upgrade and why do I need it?
 Firmware fixes bugs for your device, contains new features, and improves the experience of using the product. For your device update and security, please ask us for help. Wrong upgrade may damage your device and void the product warranty.
 For more details, please visit our website www.wavlink.com
 Our Technical Support: support@wavlink.com


11

APP Configuration

You can also set up the network on Wavlink APP except webpage configuration. Please follow the steps below for details.



- Scan the QR code on the left, you can download Wavlink APP on **Google play**, **Android market** or **Apple store**.
- Now tap the Wavlink APP, and click on "Connect" button or wait for the device SSID to appear automatically, then you can click the SSID for more configuration.



- The following steps are the same as when you configure on web UI on a browser, so continue configuring the network until it's completed.

12

FAQ

- Q1. Why doesn't the login page appear after entering <http://wifi.wavlink.com>?**
 - Make sure your PC is set to obtain IP address automatically.
 - Please make sure you entered the correct website.
 - Reboot your device and try again.
- Q2. What can I do if I can not access the Internet?**
 - Make sure your Internet works normally, please contact your ISP(Internet Service Provider) if it doesn't.
 - Initiate your browser, enter 192.168.10.1 or wifi.wavlink.com, then set up following the quick start guide.
 - Reboot your device and try again.
- Q3. What should I do if I can't have access to 192.168.10.1 or wifi.wavlink.com on my android phone?**
 - We suggest you turn off your 4G signal first before you set up the network, then turn it on when the configuration is done.
- Q4. What can I do if I forget my administration management password?**
 - Please refer to [Q3](#) to reset the device, the default password is **admin**.
- Q5. How do I find the best location for mesh devices?**
 - Please put your mesh devices in a relatively open space to avoid obstacles such as metal objects, reinforced concrete walls and so on.

Please visit https://www.wavlink.com/en_us/faq.html for more details.

13

GNU GENERAL PUBLIC LICENSE NOTICE

This product includes software codes developed by third parties. These software codes are subject to either the GNU General Public License (GPL), Version 2, June 1991 or the GNU Lesser General Public License (LGPL), Version 2.1, February 1999. You can copy, distribute, and/or modify in accordance with the terms and conditions of GPL or LGPL.

The source code should be complete, if you want us to provide any additional source code files under GNU General Public License (GPL), please contact us in these matters. We are committed to meeting the requirements of the GNU General Public License (GPL). You are welcome to contact us local office to get the corresponding software and licenses. Please inform us your contact details (full address) and the product code. We will send you a software package with the software and license for free.

The respective programs are distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Please refer to the GNU General Public License website for further information.
<http://www.gnu.org/licenses/old-licenses/lgpl-2.0.html>
<http://www.gnu.org/licenses/gpl.html>

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

14



Thank you for purchasing WAVLINK product!



WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)