harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Note: Inadequate maintenance is the most common cause of alarm failure; therefore, test your system at least once per week to be sure the sensors and sirens are working properly.

Although having an alarm system may make you eligible for reduced insurance premiums, the system is no substitute for insurance.



# RED SHIELD DOOR/WINDOW SENSOR INSTALLATION AND OPERATING INSTRUCTIONS

For use with Red Shield Wire-free Home Protection System Please keep these instructions in a safe place for future reference.

Kit contents: 1 x Red Shield Door/Window Sensor

1 x Magnetic contact 1 x Double-sided adhesive pad

1 x Instruction leaflet



#### 1. Introduction

The Red Shield Door/Window Sensor consists of two parts, a transmitter and a magnetic contact. Once this sensor is installed, with the transmitter fastened to the frame and the magnet to the door or window, the sensor will trigger and transmit a message to the Wire-free Protection System Smart Panel when the door or window is opened.

2. Location

First determine the location of the Sensor, which should be placed:

in the most vulnerable rooms or near key entry/exit points

 away from extreme temperature sources (radiators, ovens, stoves etc.) and large metal objects that could interfere with the wireless performance

away from direct sunlight.
indoors only and not behind partitions

where better RF performance can be achieved (if necessary)

# 3. Installation and Operation

3.1 Powering up the Door/Window Sensor

Remove the battery cover; insert new batteries noting the polarity as shown in Fig.1 and replace cover. (Requires 2 x AAA batteries)

Low battery indication: If the batteries need to be replaced, the RED LED on the transmitter will flash slowly.



Fig. 1

#### 3.2. Installing the Door/Window Sensor

Mount the transmitter on a fixed surface such as a door or a window frame.

Mount the magnet on a movable surface such as a door or a window.
 Ensure the >/< marks on the sides of the transmitter and magnet match up as shown in Fig.2.</li>



. 4

## The transmitter and the magnet must be no more than 5mm apart

#### **3.3. Mounting with the double-sided adhesive pad** • Ensure the mounting surface is clean.

Peel back one layer of the protective film and attach it to the transmitter.

Peel back the remaining layer of protective film and press the transmitter firmly in place against the mounting

surface until firmly attached.

· Repeat to attach the magnet.

#### 4. House Security Code Settings

Unless the factory settings of the Wire-free Home Protection System Smart Panel have been altered, the House Security Code will NOT need to be changed.

However, if the settings on the Smart Panel have been altered, or need to be altered to solve the problem of the Smart Panel and sensors activating intermittently (or not working at all) or interference with other systems, then the House Security Code on all system modules (sensors and sirens)will also need to be changed.

### House Security Code settings can be altered as follows:

There are 4 jumpers or dip-switches on each device.
 Remove the jumper compartment cover, then pull out or plug the jumper into the contacts to change the

House Security Code • If a jumper is plugged, it is ON. if it is removed, it is OFF. Default code is with all the jumpers plugged

To ensure the system works correctly, make sure the jumpers on the Smart Panel and all other system modules (sensors and sirens) match exactly.



. 2

#### 5. Zone Code Settings

The sensor is supplied with a pre-assigned Zone setting. The sensor can be assigned to a different zone as follows: • Unscrew and remove the jumper compartment cover on the rear of the sensor.

1

In the area marked "Zone Code" there are eight pairs of metal contacts with a number next to each.
The number corresponding to the pair of contacts which is plugged with a jumper is the current zone.

To re-assign to a different zone simply unplug the jumper from its current zone and plug it across the contacts corresponding to the new zone number selected.

Jumper for Zone Code 87654321	Default zone code: Zone 1
----------------------------------	---------------------------

#### 6. Maintenance

The product may be cleaned with a soft damp cloth and then wiped dry. Do not use abrasive, solvent based or aerosol cleaners as this may damage and/or discolour the product. Do not allow water to enter or attempt to clean inside the unit.

#### 7. Batteries

Do not allow the batteries to corrode or leak as this may cause permanent damage to the product. Take care to insert the batteries with the correct polarity as shown inside the battery compartments. Do not mix new and old batteries or different types of batteries. Do not use rechargeable batteries.

At the end of their useful life the batteries should be disposed of via a suitable recycling center. Do not dispose of with your normal household waste. DO NOT BURN.

#### 8. Alarm System Limitations

Even the most advanced alarm systems cannot guarantee 100% protection against burglary or environmental problems. All alarm systems are subject to possible compromise or failure-to-warn for a variety of reasons. Please note that you may encounter problems with your system if:

The sensors are not placed within hearing range of persons sleeping or remote parts of the premises.
 The sensors are placed being doors or other obstacles

Intruders gain access through unprotected points of entry (where sensors are not located).

• Intruders have the technical means of bypassing, jamming, or disconnecting all or part of the system.

The power to the sensors is inadequate or disconnected.
The sensors are not located in proper environmental/temperature conditions i.e. too close to a heat source.

FCC Regulation: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuantto Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against